

## Trustwave NAC Server Management Specifications

	M1	M10
<b>Chassis</b>		
<b>Height</b>	2U, 3.5" (8.89cm)	2U, 3.5" (8.89cm)
<b>Depth</b>	17.7" (44.96cm)	17.7" (44.96cm)
<b>Width</b>	19" (48.26cm)	19" (48.26cm)
<b>Mounting</b>	Standard Rack Mount	Standard Rack Mount
<b>Internals</b>		
<b>RAID</b>	RAID 1	RAID 1
<b>Network Ports</b>	Redundant, 1Gb/s	Redundant, 1Gb/s
<b>Storage</b>	160 GB	1 TB
<b>Power Supply</b>	Redundant, 700W	Redundant, 700W
<b>Power Requirements</b>	120V/60Hz	120V/60Hz
<b>Cooling</b>	Redundant Fan Bank	Redundant Fan Bank
<b>Startup Access</b>	Serial DB-9	Serial DB-9
<b>Management</b>		
<b>Sensor Capacity*</b>	Up to 100	Up to 1000

\*Actual deployment capacity is highly dependent on network topology; configuration and activity [e.g. network latencies, traffic volatility traversing segments, firewall placement, frequency of device access, etc.].

#### CORPORATE HEADQUARTERS

70 West Madison Street  
Suite 1050  
Chicago, IL 60602

Tel: +1 (312) 873 7500

#### EMEA HEADQUARTERS

Westminster Tower  
3 Albert Embankment  
London, SE1 7SP

Tel: +44 (0) 845 456 9611

#### ASIA-PACIFIC HEADQUARTERS

Level 2, 48 Hunter Street  
Sydney NSW 2000  
Australia

Tel: +61 (0) 2 9236 4200

#### LATIN AMERICA HEADQUARTERS

Rua Cincinato Braga, 340 nº 71 - Edifício Delta Plaza  
Bairro Bela Vista - São Paulo - SP  
CEP: 01333-010 – BRASIL

Tel: +55 (11) 4064 6101